



* Indicates dimensions for Leveling Pad centers.

- NOTES:
1. ALL HEIGHTS MEASURED FROM FLOOR LEVEL ARE NOMINAL
 2. 3 PHASE POWER SUPPLY, CONTROL BOX, FUSES & DISCONNECT TO BE SUPPLIED BY CUSTOMER. (AS REQUIRED BY N.E.C. & LOCAL CODES)
 3. DIMENSIONS SHOWN IN INCHES (MM).

N/A	-	-	-	N/A
N/A	LAYOUT, GENERAL APRICOT MACHINE & FEEDER			N/A
N/A	M. LIPFORD 03/06/97			ATLAS PACIFIC
1/16				3008.0640

3008.0640 1